

**Bowser Mfg, 1302 Jordan Ave,
PO Box 322, Montoursville PA 17754
570-368-2516
www.bowser-trains.com**

**F 3, 7 or 9
Old Stewart
production with 8 pin socket
Kit #691-1226**

Decoder is LokSound Select

Remove wires from motor slide lock.
Cut the motor slide lock off the circuit board



2 round solder spots after the slide lock removed



Solder motor wires



Solder 2 brown wires to the speaker
Cut off the mounting ears



Plug in Decoder and tape onto the circuit board
Keep everything as low as possible



Place speaker on frame
Hold in place with Kapton tape

